

Safety Valve (Pneumatic check valve)

QAX7.2



1 Overview

Safety valve is installed on the collecting pipe. The safety diaphragm blasts in order to protect the collecting pipe when the pressure in the pipeline is greater than the allowable value

2 Technical Parameter

Model	Burst pressure	Connect thread	Remark
QAX7.2	7.2Mpa	Rc1 $\frac{1}{2}$ "	Burst pressure can be adjusted according to different system working pressure