

IG541 Container Valve

HRF16/17.2



1 Overview

The container valve installed on the fire extinguishing agent storage bottle is used to seal the storage bottle of fire extinguishing agent and driving gas. When fire occurs, it's opened by the driving gas or the electromagnet valve. The driving gas pushes the fire extinguishing agent, which is then conveyed to the fire place, to put out fire.

2 Technical Parameter

Model	Nominal working pressure	Nominal diameter	Outlet thread & sealing method	Inlet thread	Siphon thread	Safe discharge pressure
HRF16/17.2	17.2MPa	16 mm	M27*1.5 Taper seal	PZ39	M16*1	23MPa